

## High Street Messenger Bag

**NOTE: We have updated the materials list for using 54" wide fabric. The yardage requirements have not changed because of the size and length of the pattern pieces.**

We have updated Step 8C on the inside of the cover. These instructions are for installing Velcro™ in place of the magnetic snap.

Please add this information to the end of Step 8C **"Set this panel (6B) aside for now."** Then, you will continue with Step 8D on the instruction page, working with the Top Flap Pocket Piece (6A) to begin making the Flap Pocket.